

Useage Noun Toro Part# Other Brand Other #

Nomenclature	ID	OD	W/L	WH P/N	Vendor
Differential Bearing Ball Bearing	1.5"			1533	S.O.L.
1-1/8" Axle Needle Bearing				9416	Torrington B-1816
Axle 1 "				1528	B-1616
Brake Shaft (old 1")	1.0000			1530	B-1612
Brake Closed end 1"	1.0000			1532	M-16121
Brake Shaft new 3/4	0.7500			1523	B-1212
Brake Closed end 3/4"	0.7500			1529	M-12121
Input open 5/8	0.3750			1508	B-1012
Input Closed end				1531	M-10121
Tiller shaft Bearing				6838	B-2016
Tiller Intermediate shaft				1532	M-16121
Tiller Input Closed				1429	M-12121
Tiller input open				1540	B-128

Seals

3/4 " Brake Shaft	0.7500			100441	C/R 7410
1" Axle -Old Brake Shaft	1.0000			1232	C/R 9815
5/8 (.625) Input Shaft	0.6250			100442	C/R 6105
1-1/8" Axle	1.1250			100443	C/R 11050
Tiller Shaft				103118	C/R 12330